



#	Code #	Part Name	AR	BR	BCR	CR	SAR
1	1701 1	Needle Cap	○	○	■	■	■
1	1701 2	Needle Cap	■	■	○	○	○
2	1702 1	.5mm Nozzle Cap	○	○	■	■	■
2	1702 2	.3mm Nozzle Cap	■	■	○	○	○
3	1704 1	.5mm Nozzle	○	○	■	■	■
3	1704 2	.3mm Nozzle	■	■	○	○	○
4-8		Airbrush Body	7	8	5	4	6
9	1725 1	.5mm Teflon Needle	○	○	■	■	■
9	1125 7	.3mm Teflon Needle	■	■	○	○	○
10	1612 1	Main Lever (Trigger)	■	■	■	■	×
11	1612 1	Main Lever (Trigger)	×	×	×	×	■
12	1715 1	.5mm Needle Chucking Guide with Auxiliary Lever	○	○	■	■	×
12	1715 1	.3mm Needle Chucking Guide with Auxiliary Lever	■	■	○	○	×
13	1135 1	Needle Spring	■	■	■	■	×
14	1770 1	Spring Guide	■	■	■	■	×
15	1617 1	.5mm Needle	×	×	■	■	■
15	1617 2	.3mm Needle	■	■	○	○	○
16	1120 2	Needle Chucking Nut	■	■	■	■	■

#	Code #	Part Name	AR	BR	BCR	CR	SAR
17	1719 1	Ergonomic Handle	■	■	■	■	×
	1155 2	Pre-Set Handle	○	○	○	○	×
	1155 6	Pre-Set Cut-Away Handle	○	○	○	○	×
18	1719 2	Ergonomic Handle	×	×	×	×	■
19	1722 1	Fluid Adjustment Knob	×	×	×	×	■
20	1718 1	Lid, Revolution CR	×	×	×	×	■
21	1580 1	Packing Valve Piston O-Ring	■	■	■	■	■
22	1608 1	Air Valve Guide Body	■	■	■	■	■
23	1609 2	Air Valve	■	■	■	■	■
24	1035 1	Air Valve Spring	■	■	■	■	■
25	1611 1	Air Valve Guide Screw	■	■	■	■	■
	1765 1	Spanner (The Iwata Wrench)	■	■	■	■	■
	1405 2	.75 oz. Glass Bottle	×	×	■	×	■
	1420 2	1.5 oz. Glass Bottle	×	×	■	×	■

■ = Standard
 × = No
 ○ = Optional