



Eclipse Parts Guide



#	Code #	Part Name	BCS	BS	CS
1	1 601 1	Needle Cap	■	■	■
	1 105 0	Crown Cap	○	○	○
2	1 602 1	.5mm Nozzle Cap	■	○	○
2	1 602 2	.35mm Nozzle Cap	○	■	■
3	1 603 1	Head Cap	■	■	■
4	1 604 1	.5mm Nozzle	■	○	○
4	1 604 2	.35mm Nozzle	○	■	■
5	1 605 1	Packing Head O-Ring	■	■	■
6		Airbrush Body			
7	1 580 1	Packing Valve Piston	■	■	■
		O-Ring			
8	1 608 1	Air Valve Guide Body	■	■	■
9	1 609 1	Air Valve	■	■	■
10	1 510 4	Air Valve Spring	○	■	■
10	1 035 1	Air Valve Spring	■	○	○
11	1 611 1	Air Valve Guide Screw	■	■	■
12	1 612 1	Main Lever (Trigger)	■	■	■
13	1 725 1	Teflon Needle Packing Set	■	■	■
14	1 715 1	Needle Chucking Guide	■	■	■
		Auxiliary Lever			
15	1 135 1	Needle Spring	○	■	■
15	1 135 2	Needle Spring	■	○	○



#	Code #	Part Name	BCS	CS	SBS
16	1 170 2	Spring Guide	■	■	■
18	1 617 1	.5mm Needle	■	○	○
18	1 617 2	.35mm Needle	●	■	■
19	1 619 1	Single Cut Handle	■	■	■
	1 155 2	Pre-Set handle	○	○	○
	1 155 6	Pre-Set Cut-Away Handle	○	○	○
21	1 618 1	Lid, Eclipse CS	×	×	■
	1 095 7	Lid, 1/4oz Side Cup	×	×	×
	1 718 1	Lid, 1/3oz Gravity Cup	×	×	○
	1 095 8	Lid, 1/2oz Gravity Cup	×	×	×
22	1 070 3	1/8oz Side Cup	×	×	×
	1 070 4	1/4oz Side Cup	×	×	×
	1 720 1	1/3oz Gravity Cup	×	×	×
	1 070 6	1/2oz Gravity Cup	×	×	×
22a	1 095 6	1/8 / 1/4oz Lower Lid	×	×	×
22b	1 150 5	Packing Lower Lid	×	×	×
23	1 045 2	Blanking Screw	×	×	×

■ = Standard
 × = No
 ○ = Optional

